








|  AIR CONDITIONING | CSP ULTIMATE | CSP STANDARD PLUS |
|--|--------------|-------------------|
| Air Conditioning Compressor Brackets | ✓ | |
| Air Conditioning Housing, Levers and Linkage | ✓ | |
| Air Conditioning/Heater Blower Motor | ✓ | |
| Air Conditioning Power Module | ✓ | |
| Air/Recirculation Housing Door | ✓ | |
| Blower Motor Resister | ✓ | |
| Compressor Clutch | ✓ | ✓ |
| Clutch Cycling Switch | ✓ | ✓ |
| Compressor Clutch Coil | ✓ | ✓ |
| Compressor | ✓ | ✓ |
| Condenser | ✓ | |
| Cool Air/Vent Control Cables | ✓ | |
| Evaporator | ✓ | ✓ |
| Expansion Valve | ✓ | |
| Heater Core | ✓ | |
| Heater Housing | ✓ | |
| Heater Mode Control Cable | ✓ | |
| Heater/Defroster Doors | ✓ | |
| High Pressure Cut-Off Switch | ✓ | |
| Instrument Panel Control Assembly | ✓ | |
| Low Pressure Cut-Off Switch | ✓ | |
| Module Blower Motor Control | ✓ | |
| Motor/Actuator, Fresh Air/Recirculation | ✓ | |
| Motor/Actuator, Mode Door | ✓ | |
| Rear Air Conditioning Assembly | ✓ | |
| Receiver-Drier | ✓ | |
| Seals and Gaskets | ✓ | |
| Temperature/Blend Air Door | ✓ | |
| Thermistor Probe | ✓ | |


|  BODY | CSP ULTIMATE | CSP STANDARD PLUS |
|--|--------------|-------------------|
| Adjustable Cup Holder Mechanisms | ✓ | |
| Center Console Door, Hinge and Lock | ✓ | |
| Convertible Top Cylinders, Lines and Hinges | ✓ | |
| Convertible Top Frame, Bows and Rails | ✓ | |
| Door Check Straps | ✓ | |
| Door Glass Tracks and Channels | ✓ | |
| Door, Hood and Trunklid Hinges | ✓ | |
| Hood Latch Release Cable | ✓ | |


|  BODY | CSP ULTIMATE | CSP STANDARD PLUS |
|---|--------------|-------------------|
| Hood Props | ✓ | |
| Liftgate Props | ✓ | |
| Spare Tire Hanger/Carrier | ✓ | |
| Spare Tire Jack | ✓ | |
| Washer Nozzles | ✓ | |
| Wiper Arm Linkage | ✓ | |


|  BRAKES | CSP ULTIMATE | CSP STANDARD PLUS |
|---|--------------|-------------------|
| Adjustable Brake Pedal Assembly | ✓ | |
| Power Brake Booster | ✓ | ✓ |
| Brake Fluid Reservoir | ✓ | |
| Metal Lines | ✓ | |
| Brake System Hydraulic Assembly and Controller | ✓ | |
| Disc Brake Calipers | ✓ | ✓ |
| Master Cylinder | ✓ | ✓ |
| Parking Brake Cable | ✓ | ✓ |
| Parking Brake Linkage | ✓ | ✓ |
| Parking Brake Handle | ✓ | |
| Parking Brake Cable Adjuster | ✓ | |
| Proportioning Valve | ✓ | ✓ |
| Pump Motor Assembly | ✓ | |
| Seals and Gaskets | ✓ | |
| Sensors and Relays | ✓ | |
| Wheel Bearing Assemblies | ✓ | |
| Wheel Cylinders | ✓ | ✓ |

|  DRIVELINE/TRANSAXLE | CSP ULTIMATE | CSP STANDARD PLUS |
|--|--------------|-------------------|
| Axle Housing and All Internal Parts | ✓ | ✓ |
| Axle Shaft Bearings | ✓ | ✓ |
| Axle Shafts | ✓ | ✓ |
| Constant Velocity Joints and Boots | ✓ | ✓ |
| Differential Carrier Assembly and All Internal Parts | ✓ | ✓ |
| Differential Cover | ✓ | |
| Disconnect Housing Assembly | ✓ | |
| Drive Shaft Assemblies | ✓ | ✓ |
| Drive Shaft Center Bearings | ✓ | |
| End Cover | ✓ | |




|  DRIVELINE/TRANSAXLE | CSP ULTIMATE | CSP STANDARD PLUS |
|---|--------------|-------------------|
| Front and Rear Axle Housing Assemblies and All Internal Parts | ✓ | ✓ |
| Front Wheel Bearings | ✓ | |
| Oil Pan | ✓ | |
| Output Ball Bearing | ✓ | ✓ |
| Output Flange | ✓ | ✓ |
| Overrunning Clutch | ✓ | ✓ |
| Pinion Spacer and Shim | ✓ | ✓ |
| Power Transfer Unit and All Internal Parts | ✓ | ✓ |
| PRNDL Position Switch | ✓ | |
| Rear Axle Housing and All Internal Parts | ✓ | ✓ |
| Rear Driveline Module | ✓ | |
| Seals and Gaskets | ✓ | ✓ * |
| Torque Converter | ✓ | ✓ |
| Torque Tube | ✓ | |
| Transaxle Case and All Internal Parts | ✓ | ✓ |
| Transaxle Electronic Controller | ✓ | ✓ |
| Transaxle Solenoid Assembly | ✓ | |
| Transaxle Speed Sensor | ✓ | |
| Transfer Case/Power Transfer Unit and All Internal Parts | ✓ | ✓ |
| Universal Joints and Yokes | ✓ | ✓ |
| Viscous Coupler | ✓ | |


|  ELECTRICAL | CSP ULTIMATE | CSP STANDARD PLUS |
|--|--------------|-------------------|
| Air Bag and Side Air Bag Control Modules | ✓ | |
| All Relays | ✓ | |
| Wiring Harnesses | ✓ | ✓ |
| Automatic Headlamp Sensor | ✓ | |
| Auxiliary 12-Volt Power Outlet | ✓ | |
| Auxiliary 115-Volt Power Outlet and A/C Inverter | ✓ | |
| Battery Heater | ✓ | |
| Battery Hold Down | ✓ | |
| Body Computer | ✓ | |
| Body Control Module | ✓ | |
| Cigar Lighter Assembly | ✓ | |
| Coil Pack Assembly | ✓ | |
| Compass Sensor Module | ✓ | |
| Daytime Running Lights Module | ✓ | |
| Distributor | ✓ | ✓ |


|  ELECTRICAL | CSP ULTIMATE | CSP STANDARD PLUS |
|---|--------------|-------------------|
| Electronic Fuel Injection System (Excluding Clogged Injectors) | ✓ | |
| Electronic Stability Program | ✓ | |
| Ignition Control Module | ✓ | ✓ |
| Factory Installed Radios and Speakers | ✓ | |
| Fuse/Relay Block | ✓ | |
| Garage Door Opener Transmitter | ✓ | |
| Alternator | ✓ | ✓ |
| Generator/Alternator Pulley, Bracket and Adaptor | ✓ | |
| Glow Plugs | ✓ | |
| Hands Free Cellular Telematics | ✓ | |
| Heated Seat Control Module | ✓ | |
| Heated Seat Element Pads and Module | ✓ | |
| Hill Descent Control | ✓ | |
| Hill Start Assist | ✓ | |
| Horn and Horn Pad | ✓ | |
| Ignition Coil | ✓ | |
| Low Tire Pressure Sensors | ✓ | |
| Manually Operated Electrical Switches | ✓ | ✓ |
| Memory Seat Control Module | ✓ | |
| Occupant Classification System Module | ✓ | |
| Oil Pressure Sending Unit/Switch | ✓ | |
| Park Neutral Position Switch | ✓ | |
| Audible Rear Back Up Warning System | ✓ | |
| Rear Back Up Camera/Monitor System | ✓ | |
| Power Door/Liftgate Motor | ✓ | |
| Power Folding Seat Motors | ✓ | |
| Power Sliding Door/Liftgate Module | ✓ | |
| Powertrain Control Module | ✓ | |
| Quarter Vent Window Motor | ✓ | |
| Rear Seat Video Systems | ✓ | |
| Rear Window Wiper Motor | ✓ | |
| Remote Start Systems (OEM) | ✓ | |
| Satellite Radio System | ✓ | |
| Satellite Television System | ✓ | |
| Security Alarm System | ✓ | |
| Sensor, Charge/Air Inlet Temperature | ✓ | |
| Sliding Door Alert Warning System | ✓ | |
| Starter Motor | ✓ | ✓ |
| Temperature Sending Unit/Switch | ✓ | |





|  ELECTRICAL | CSP ULTIMATE | CSP STANDARD PLUS |
|---|--------------|-------------------|
| Tire Pressure Monitor/Warning System | ✓ | |
| Traction Control System | ✓ | |
| Trailer Sway Damping System | ✓ | |
| Transmission Control Module | ✓ | ✓ |
| USB Port | ✓ | |
| Voltage Regulator | ✓ | ✓ |
| Washer Fluid Reservoir and Pump/Motor | ✓ | |
| Windshield Wiper Motor | ✓ | ✓ |
| Wiper Control Module | ✓ | |

|  ENGINE | CSP ULTIMATE | CSP STANDARD PLUS |
|---|--------------|---------------------------|
| Air Cleaner Assembly (Excluding Element) | ✓ | |
| Core Plugs | ✓ | |
| Cylinder Block and All Internal Parts | ✓ | ✓ |
| Cylinder Head Assemblies | ✓ | ✓ |
| Engine Supports/Mounts | ✓ | |
| Flex Plate/Drive Plate | ✓ | |
| Flywheel | ✓ | ✓ |
| Electric Fuel Pump & Diesel Injector Pump | ✓ | ✓ |
| Fuel Injectors (Excluding Clogged Injectors) | ✓ | |
| Harmonic Balancer | ✓ | ✓ |
| Secondary Air Supply | ✓ | |
| Idler Pulley | ✓ | |
| Intake and Exhaust Manifolds | ✓ | ✓ |
| Oil Filter Adapter Housing | ✓ | |
| Oil Pan | ✓ | ✓ |
| Oil Pump | ✓ | ✓ |
| Pulleys and Sprockets | ✓ | |
| Pump, Air | ✓ | |
| Pump, Leak Detection | ✓ | |
| Seals and Gaskets | ✓ | Listed covered parts only |
| Serpentine Belt Tensioner | ✓ | |
| Supercharger | ✓ | ✓ |
| Timing Case, Chain, Gears | ✓ | ✓ |
| Turbocharger Housing and All Internal Parts | ✓ | ✓ |
| Turbocharger Waste Gate Actuator | ✓ | |
| Valve Covers | ✓ | ✓ |
| Valve, Exhaust Gas Recirculation Control | ✓ | |
| Water Pump and Housing | ✓ | Water Pump Only |

|  COOLING | CSP ULTIMATE | CSP STANDARD PLUS |
|---|--------------|-------------------|
| Coolant Recovery Bottle | ✓ | |
| Coolant Temperature Switch | ✓ | |
| Cooling Fan, Clutch and Motor | ✓ | |
| Engine Oil Cooler | ✓ | |
| Radiator | ✓ | |
| Radiator Cap | ✓ | |
| Radiator Fan Shroud | ✓ | Electric Only |
| Seals and Gaskets | ✓ | |
| Serpentine Belt Tensioner | ✓ | |
| Thermostat | ✓ | |
| Turbocharger Coolant Tube/Line | ✓ | |
| Water Pump and Housing | ✓ | Water Pump Only |
| Water Pump Transfer Tube and O-Rings | ✓ | |

|  FUEL | CSP ULTIMATE | CSP STANDARD PLUS |
|--|--------------|--------------------|
| Accelerator Pedal and Linkage | ✓ | |
| Evaporation Canister | ✓ | |
| Fuel Pump | ✓ | Electric Pump Only |
| Fuel Tank | ✓ | |
| Fuel Tank Filler Cap and Door | ✓ | |
| Fuel Tank Sending Unit | ✓ | |
| Speed Control/Throttle Body Cables | ✓ | |

|  INSTRUMENT PANEL | CSP ULTIMATE | CSP STANDARD PLUS |
|--|--------------|-------------------|
| Amp/Voltmeter Gauge | ✓ | |
| Clock | ✓ | |
| Electronic Instrument Cluster | ✓ | |
| Fuel Gauge | ✓ | |
| Oil Pressure Gauge | ✓ | |
| Speedometer | ✓ | ✓ |
| Tachometer | ✓ | |
| Temperature Gauge | ✓ | |
| Turbo Gauge | ✓ | |

|  LUXURY GROUP | CSP ULTIMATE | CSP STANDARD PLUS |
|--|--------------|-------------------|
| Convertible Top Motor | ✓ | |
| Cruise Control Servo | ✓ | |
| Electric Mirror Motor and Controls | ✓ | |



| LUXURY GROUP | CSP ULTIMATE | CSP STANDARD PLUS |
|--|--------------|-------------------|
| Electronic Vehicle Information Center | ✓ | |
| Headlight Door Motor | ✓ | |
| Heated Seat Elements | ✓ | |
| Keyless Entry Receiver/Module | ✓ | |
| Message Center | ✓ | |
| Overhead Electronic Compass/Temperature | ✓ | |
| Overhead Electronic Vehicle Information Center | ✓ | |
| Power Sunroof Motor | ✓ | |
| Trip Computer | ✓ | |

| MANUAL INTERIOR MECHANISMS | CSP ULTIMATE | CSP STANDARD PLUS |
|---|--------------|-------------------|
| Seat Base Riser | ✓ | |
| Seat Belt Shoulder Height Adjuster/Knob | ✓ | |
| Seat Lumbar Adjuster | ✓ | |
| Seat Manual Height Adjuster | ✓ | |
| Seat Manual Track Adjuster | ✓ | |
| Seat Recliner Assembly | ✓ | |

| POWER GROUP | CSP ULTIMATE | CSP STANDARD PLUS |
|------------------------------|--------------|-------------------|
| Decklid Release Cable | ✓ | |
| Power Antenna | ✓ | |
| Power Door Locks and Linkage | ✓ | |
| Power Seat Motors | ✓ | |
| Power Sliding Door Motors | ✓ | |
| Power Window Motors | ✓ | |
| Rear Window Defroster | ✓ | ✓ |

| SAFETY & SECURITY | CSP ULTIMATE | CSP STANDARD PLUS |
|---------------------------------|--------------|-------------------|
| Air Bags | ✓ | |
| Air Bag Clock Spring | ✓ | |
| Air Bag Sensors | ✓ | |
| Door Lock Cylinders | ✓ | |
| Hazard Warning Lamps and Relays | ✓ | |

| SAFETY & SECURITY | CSP ULTIMATE | CSP STANDARD PLUS |
|---|--------------|-------------------|
| Ignition Switch Lock Cylinder | ✓ | |
| Seat Belt Assemblies | ✓ | |
| Trunk Emergency Release Cable & Mechanism | ✓ | |

| STEERING | CSP ULTIMATE | CSP STANDARD PLUS |
|--|--------------|-------------------|
| Power Steering Cooler | ✓ | ✓ |
| Power Steering Gear | ✓ | ✓ |
| Power Steering Pump | ✓ | ✓ |
| Power Steering Pump Pulley | ✓ | ✓ |
| Power Steering Pump Reservoir and Cap | ✓ | |
| Rack and Pinion Assembly | ✓ | ✓ |
| Seals and Gaskets | ✓ | ✓ |
| Steering Column Assembly | ✓ | |
| Steering Damper | ✓ | |
| Steering Gear Housing and All Internal Parts | ✓ | ✓ |
| Steering Shaft Lower Coupling | ✓ | |
| Steering Wheel Tilt Lever | ✓ | |

| SUSPENSION | CSP ULTIMATE | CSP STANDARD PLUS |
|------------------------------------|--------------|-------------------|
| Auxiliary Springs | ✓ | |
| Trac Bar | ✓ | |
| Bushing Stabilizer Bar | ✓ | |
| Control Arm Bushings | ✓ | |
| Control Arms | ✓ | |
| Cushion Stabilizer Bar | ✓ | |
| Front Axle Crossmember | ✓ | |
| Front Axle Vent | ✓ | |
| Front Control Arm Bushings | ✓ | ✓ |
| Front Control Arms | ✓ | ✓ |
| Front Spring Bushing | ✓ | |
| Front Spring Hanger | ✓ | |
| Front Spring Interliner | ✓ | |
| Front Spring Seat | ✓ | |
| Front Spring Shackle | ✓ | |
| Front Stabilizer/Sway Bar Link | ✓ | ✓ |
| Front Upper and Lower Ball Joints | ✓ | ✓ |
| Front Upper and Lower Control Arms | ✓ | ✓ |
| Lateral Link Arm | ✓ | |
| Link Stabilizer Bar | ✓ | |



| SUSPENSION | CSP ULTIMATE | CSP STANDARD PLUS |
|----------------------------------|--------------|-------------------|
| Rear Auxiliary Springs | ✓ | |
| Rear Axle Trac Bar | ✓ | |
| Rear Camber, Spring, Toe, Links | ✓ | |
| Rear Coil Springs | ✓ | |
| Rear Lateral Link Arm | ✓ | |
| Rear Leaf Springs | ✓ | |
| Rear Shock Mount Plate | ✓ | |
| Rear Springs | ✓ | |
| Rear Spring Bushing | ✓ | |
| Rear Spring Hanger | ✓ | |
| Rear Spring Interliner | ✓ | |
| Rear Spring Shackle | ✓ | |
| Rear Stabilizer/Sway Bar | ✓ | |
| Rear Stabilizer/Sway Bar Bushing | ✓ | |
| Rear Stabilizer/Sway Bar Link | ✓ | |
| Rear Trailing Arm Assembly | ✓ | |
| Shock Mount Plate | ✓ | |
| Stabilizer/Sway Bar | ✓ | Front Only |
| Strut Assemblies | ✓ | |
| Suspension Knuckles | ✓ | |
| U-Bolt Rear Spring | ✓ | |

| TRANSMISSION (AUTOMATIC) | CSP ULTIMATE | CSP STANDARD PLUS |
|--|--------------|-------------------|
| Automatic Transmission Case and All Internal Parts | ✓ | ✓ |
| Drive/Flex Plate | ✓ | |
| Seals and Gaskets | ✓ | ✓ |
| Torque Converter | ✓ | ✓ |
| Transmission Control Module | ✓ | ✓ |
| Transmission Cooler | ✓ | |
| Transmission Oil Pan | ✓ | |
| Transmission Range Switch | ✓ | |
| Transmission Shifter Interlock Solenoid | ✓ | |

| TRANSMISSION (CVT) | CSP ULTIMATE | CSP STANDARD PLUS |
|---|--------------|-------------------|
| Continuously Variable Transmission and All Internal Parts | ✓ | ✓ |
| CVT Belt | ✓ | ✓ |
| CVT Neutral, Safety, Backup Switch | ✓ | |
| Forward and Reverse Clutch | ✓ | ✓ |

| TRANSMISSION (CVT) | CSP ULTIMATE | CSP STANDARD PLUS |
|---------------------------|--------------|-------------------|
| Input Speed Sensor | ✓ | |
| Output Speed Sensor | ✓ | |
| Planetary Gearset | ✓ | ✓ |
| Primary Variator | ✓ | ✓ |
| Seals and Gaskets | ✓ | ✓ |
| Secondary Variator | ✓ | ✓ |

| TRANSMISSION (CVT) | CSP ULTIMATE | CSP STANDARD PLUS |
|---|--------------|-------------------|
| Bell Housing | ✓ | ✓ |
| Clutch Hydraulic Fluid Reservoir | ✓ | |
| Clutch Master Cylinder | ✓ | |
| Clutch Release Cable | ✓ | |
| Clutch Release Fork | ✓ | |
| Clutch Slave Cylinder | ✓ | |
| Gear Shift Lever Assembly | ✓ | |
| Gear Shift Linkage | ✓ | |
| Manual Transmission Case and All Internal Parts | ✓ | ✓ |
| Seals and Gaskets | ✓ | ✓ |
| Shifter Lock Cable | ✓ | |

Choose one of our factory backed coverage options.

CSP STANDARD PLUS:

This plan provides good coverage protecting you from unforeseen costly repairs.*

ULTIMATE CARE:

This plan provides the best coverage against unforeseen costly repairs, covering over 5000 parts.*

Secure Coverage Today: gofordcsp.com

The above are the most common parts that are covered under each plan. Please refer to actual plan for parts and services that are not covered and other exclusions that may apply.

* Please see contract terms and conditions or contact a Ford Protect CSP Coverage Expert for a list of covered repairs.

Ford Protect® Continued Service Plan (CSP) has been created to provide coverage after the expiration of your Ford Protect Plan. Ford Protect CSP offers similar coverage to your existing Ford Protect but is not a duplication of your Ford Protect coverage. In Florida, Ford Protect CSP on Ford, Lincoln, and Mercury vehicles is a Service Contract from FMSC (License #42722). In North Dakota, Nebraska, and Washington, Ford Protect CSP is a Service Contract from Ford Motor Service Company. In Texas, CSP is a Service Contract from Ford Motor Service Company (License #SCP-165). Ford Protect CSP is not available for sale in California.